

# SCAN WHEN USING WITH THE JCM TERMINAL

## Return to Factory Defaults



SET DEFAULTS

# SCAN WHEN USING WITH THE QEC



Symbol Native API (SNAPI) without Imaging Interface